Stone EDGE SURFACES Professional Grade Concrete Overlays



Stone Edge Surfaces Concrete Overlay REPAIR and Refurbishment System uses our industry leading and ASTM compliant concrete overlay products to repair damaged, spalled, cracked, and broken concrete driveway, patio, pool deck, walkways and more, then overlay them to create functional and stunning looks. Our Driveway, Patio and Deck REPAIR and Refurbishment Systems is for commercial and residential use on stable repairable concrete substrates. Typically only three (3) of our professional mixes are used for each application type, with our incredible Pro Bond and/or CPR Concrete Patch and Repair products being applied first to repair the substrate before applying the overlay material to refurbish the look. For STAMPED, carved, heavy texture looks, use Stamp Mix and Primer 100. For KNOCKDOWN, spray, skip trowel type finishes use Pro Spray Mix and Primer 100. For BROOM or Trowel finishes use Trowel Mix and Primer 100 or use our new Smooth Coat with no primer. All Stone Edge Surfaces concrete patch, repair and overlay mixes used in our Concrete REPAIR and Refurbishment Systems are "just add water" single component mixes. Stone Edge Surfaces products are known for their ease of use, flexural strength, high PSI, long lasting wear, and are manufactured in our own factories to ensure consistent quality.

MOST COMMON USES:

- PatioFloorsPool IDeck
- Pool DeckDeckDeckResidential
 - ay Walkway ntial • Commercial

APPLICATION

BASE/TOP COAT: Base Coat: Pro Bond. Top Coat Stamp, Trowel or Spray Mix.

THICKNESS: Pro Bond: 1/16" to 4", Stamp & Trowel Mix: 1/4" to 3/8" average. Slurry/Smooth Coat 1/32" - 1/8", Spray/Texture Coat 1/32" - 1/8"

APPLICATION METHOD: Trowel, Gauge Rake, Magic Trowel, Mortar Sprayer, Pump(Pro Bond & Smooth Coat)

WORKING TIME: 15 min to 2 hrs per Coat

PRODUCTS USED WITH: Liquid colors, Integral Colors, Pro Seal, varied Sealers, Smooth Coat

COMMONLY APPLIED OVER:

Concrete....Plywood with proper prep

DRIVEWAY, PATIO & DECK repair & refurbish system

For "repair" & refurbishment of spalled, cracked, and damaged concrete Class A ASTM E84-19b Stamp Mix Primer 100 Pro Bond and CPR **Damaged or Spalled Concrete Spray Mix** Class A ASTM E84-19b **Spray Mix** ANSI 2.5 . NFPA 255 UBC 8-1 (42-1) . UL 72 Primer 100 **Pro Bond and CPR Damaged or Spalled Concrete** Class A Trowel Mix STM E84-19 Primer 100 Pro Bond and CPR **Damaged or Spalled Concrete**

For additional installation examples, images and training Videos, visit us online, call or email:

www.stoneedgesurfaces.com | 844-786-6333 info@stoneedgesurfaces.com

Stone Edge Surfaces Division - Turley International Resources, LLC 4322 South 80th Street, Mesa, AZ 85212